


## PROCEDURE




**1.** Centrifuge the must sample before withdrawal.



**2.** Collect 1000  $\mu\text{L}$  of beer with the proper pipette and pour it into an empty cuvette. Close it with the supplied cap.




**3.** Place the cuvette containing the sample in one of the incubation cells and leave it to incubate for at least 5 minutes.




**4.** Gently shake the cuvette 2-3 times.




**5.** Select the cuvette to be read from the display. Place the cuvette in the cell marked with the blue light and press READ.




**6.** Collect 20  $\mu\text{L}$  of R2 with the pipette.



**7.** Carefully clean the outside of the pipette tip with blotting paper, avoiding contact between the extremity of the tip and the paper.



**8.** Place 20  $\mu\text{L}$  of reagent R2 in the cuvette. Keeping the tip immersed in reagent, press and release the piston of the pipette several times.



**9.** Gently shake the cuvette 2-3 times.



**10.** Place the cuvette in the cell marked with the blue light and press READ to perform the photometric reading.