




## PROCEDURE




**1.** Draw the sample with the pipette 2-3 times and release it on blotting paper before collecting it for the test. Then collect 5  $\mu$ L of sample.



**2.** Carefully clean the outside of the pipette tip with blotting paper, avoiding contact between the extremity of the tip and the paper.



**3.** Place the sample in the cuvette. Keeping the tip immersed in reagent, press and release the piston of the pipette several times.




**4.** Gently shake the cuvette 2-3 times.




**5.** Place the cuvette in one of the incubation cells and start the timer by pressing the timer icon.



**6.** Select the cuvette to be read from the display. Place the cuvette in the cell marked with the blue light and press READ.




**7.** Add 2 drops of R2 to the cuvette containing R1 + sample, and shake.



**8.** Gently shake the cuvette 2-3 times.



**9.** Place the cuvette in one of the incubation cells and start the timer by pressing the timer icon.



**10.** Gently shake the cuvette 2-3 times.



**11.** Place the cuvette in the cell marked with the blue light and press READ to perform the photometric reading.