



PROCEDURE




1. Homogenize the sample: place 10gr of sample in a small glass, add 1gr of polymer and mix for a few minutes, using for example a magnetic shaker. Place part of the emulsion in a test tube and centrifuge for 5 minutes at 5000 rpm. Use the separated solution.




2. Draw the sample with the pipette 2-3 times and release it on blotting paper before collecting it for the test. Then collect 10 μ L of sample.



3. Carefully clean the outside of the pipette tip with blotting paper, avoiding contact between the extremity of the tip and the paper.



4. Place the sample in the cuvette. Keeping the tip immersed in reagent, press and release the piston of the pipette several times.



5. Gently shake the cuvette 2-3 times.




6. Place the cuvette in one of the incubation cells and start the timer by pressing the timer icon.



7. Select the cuvette to be read from the display. Place the cuvette in the cell marked with the blue light and press READ.




8. Add 1 drop of R2 to the cuvette containing R1 + sample and shake.



9. Gently shake the cuvette 2-3 times.



10. Place the cuvette in one of the incubation cells and start the timer by pressing the timer icon.



11. Gently shake the cuvette 2-3 times.



12. Place the cuvette in the cell marked with the blue light and press READ to perform the photometric reading.